

$\hat{O} [^{\wedge} \& c [! \acute{E} \acute{O} \acute{\alpha} \bullet \wedge \acute{A} X [c \acute{\alpha} \bullet \wedge$	XÔÓU	ĩ€Á	XÁ
$\hat{O} [^{\wedge} \& c [! \acute{E} \acute{O} \{ \acute{\alpha} c c \wedge ! \acute{A} X [c \acute{\alpha} \bullet \wedge$	XÔÒU	l€Á	XÁ
$\hat{O} \{ \acute{\alpha} c c \wedge ! \acute{E} \acute{O} \acute{\alpha} \bullet \wedge \acute{A} X [c \acute{\alpha} \bullet \wedge$	XÒÓU	J	XÁ
$\hat{O} [^{\wedge} \& c [! \acute{A} \hat{O} \sim ! ! \wedge \} c \acute{A} \acute{E} \hat{O} [] c \acute{\alpha} \} \sim [\sim \bullet$	QÔ	FÉÍÁ	œÁ
$\hat{O} [^{\wedge} \& c [! \acute{A} \acute{U} [, \wedge ! \acute{A} \hat{O} \acute{\alpha} \bullet \bullet \acute{\alpha}] \acute{\alpha} c \acute{\alpha} []$	ÚÔ	€ÈJÁ	Y
$R \sim \} \& c \acute{\alpha} [] \acute{A} V \wedge \{] \wedge ! \acute{\alpha} c \sim ! \wedge$	VR	FÍ€	
$\acute{U} c [! \acute{\alpha} \bullet \wedge \acute{A} V \wedge \{] \wedge ! \acute{\alpha} c \sim ! \wedge$	V•c*	ÉíÍÁdÉFÍ€	

DUFU a YhYf'	Gm a Vc'	HYgh' 7 cbX[h]cbg				
Collector-base breakdown voltage	V(BR)CBO		700			V
Collector-emitter breakdown voltage	V(BR)CEO	IC= 10mA, IB=0	400			V
Emitter-base breakdown voltage	V(BR)EBO		9			V
Collector cut-off current	ICBO	VCB= 700V, IE=0			100	µA
Collector cut-off current	ICEO	VCE= 400V, IB=0			50	µA
Emitter cut-off current	IEBO				10	µA
DC current gain	hFE	VCE= 10V, IC= 0.4 A		FB		

